PHILIPS VIDEOPAC 21







Secret of the pharaohs
Secret des pharaons
Het geheim van de farao's
Das Geheimnis der Pharaonen
Il segreto del faraone
Farao's hemmelighed
Faraos hemlighet
El secreto de los faraones



PHILIPS

ENGLISH

Secret of the pharaohs
(2 players) Press RESET
next press any key

You see two pyramids, one is upside down.

Two pyramid builders, one on either side, have to compete in trying to solve the mystery of the pyramid.

They have to place one stone into each block of their pyramid, starting with the longest row of four.
First they have to pick up a stone from their pile. Use the joystick to direct your man to his pile of stones, then press the button of your handset. You'il find that the stones are rather heavy and not quite so easy to pick up sometimes. Don't give up however.

The stones can be put either on the right- or left-hand side in each block. When one line has been completed, a number appears to indicate how many stones are in the right position. The pyramid builders now have to move the stones until they are all in the right position. Only then can they continue on with the next row of blocks etc.

The winner is the one who has first solved the mystery and has all stones in the right position. He grows in stature, blows his trumpet triumphantly while his opponent sinks down at his feet, totally exhausted.

Each time a game is finished, press RESET (△), 'SELECT GAME' is shown on the screen. Now:

(a) Select another game.
Or (b) Select another Videopac.
Remove existing Videopac by placing one hand next to it, and pulling handle upwards.
Replace Videopac in its box.
Refer now to Instructions for Use of the next Videopac.
Or (c) Plug aerial back into TV, and unplug the Videopac Computer from the mains.

Check procedure
If you suspect a fault in the equipment follow this procedure (with a Videopac installed).
Press RESET (△). The TV will emit a short sound, and 'SELECT GAME' should appear on your TV screen.
If not, ensure that the equipment is set up properly as detailed in the Instructions for Use (both of the equipment, and of the Videopac used). If the fault remains, take both the equipment and Videopac to your dealer.



Start of game

Use joystick to direct builder. Press button to either pick up or drop stone.



Game situation



Game completed

A copyright protection is claimed
on the program stored within the cartridge.

© 1980 N.V. Philips' Gloeilampenfabrieken

3111 106 60910

SIP